



ENCLOSED STARTERS FROM KEMPSTON CONTROLS

**KEMPSTON
CONTROLS**

CALL: 01933 411411 FAX: 01933 410211

Part Number	KW Rating	Item Description	List Price
Compact DOL Range			
DOLC5.5230	5.5	LOVATO L-STARTER 5.5KW COMPACT DOL 230V	£ 28.46
DOLC5.5400	5.5	LOVATO L-STARTER 5.5KW COMPACT DOL 400V	£ 28.46
Standard DOL Range			
DOLS5.5230	5.5	LOVATO L-STARTER 5.5KW DOL 230V COIL	£ 30.00
DOLS5.5400	5.5	LOVATO L-STARTER 5.5KW DOL 400V COIL	£ 30.00
DOLS7.5230	7.5	LOVATO L-STARTER 7.5KW DOL 230V COIL	£ 34.62
DOLS7.5400	7.5	LOVATO L-STARTER 7.5KW DOL 400V COIL	£ 34.62
DOLS11230	11	LOVATO L-STARTER 11KW DOL 230V COIL	£ 45.38
DOLS11400	11	LOVATO L-STARTER 11KW DOL 400V COIL	£ 45.38
Standard DOL Range & Isolator			
DOLSW5.5230	5.5	LOVATO L-STARTER 5.5KW DOL 230V + ISOL	£ 84.62
DOLSW5.5400	5.5	LOVATO L-STARTER 5.5KW DOL 400V + ISOL	£ 84.62
DOLSW7.5230	7.5	LOVATO L-STARTER 7.5KW DOL 230V + ISOL	£ 87.69
DOLSW7.5400	7.5	LOVATO L-STARTER 7.5KW DOL 400V + ISOL	£ 87.69
DOLSW11230	11	LOVATO L-STARTER 11KW DOL 230V + ISOL	£ 95.38
DOLSW11400	11	LOVATO L-STARTER 11KW DOL 400V + ISOL	£ 95.38
Reversing DOL Range			
DOLR5.5230	5.5	LOVATO L-STARTER 5.5KW REVERSER 230V	£ 80.00
DOLR5.5400	5.5	LOVATO L-STARTER 5.5KW REVERSER 400V	£ 80.00
DOLR7.5230	7.5	LOVATO L-STARTER 7.5KW REVERSER 230V	£ 84.62
DOLR7.5400	7.5	LOVATO L-STARTER 7.5KW REVERSER 400V	£ 84.62
DOLR11230	11	LOVATO L-STARTER 11KW REVERSER 230V	£ 120.00
DOLR11400	11	LOVATO L-STARTER 11KW REVERSER 400V	£ 115.38
Star-Delta Starter Range - (Overload needs to be selected at 0.58 x Motor FLC)			
YD11230	11	LOVATO L-STARTER 11KW STAR-DELTA 230V	£ 184.62
YD11400	11	LOVATO L-STARTER 11KW STAR-DELTA 400V	£ 184.62
YD15230	15	LOVATO L-STARTER 15KW STAR-DELTA 230V	£ 192.31
YD15400	15	LOVATO L-STARTER 15KW STAR-DELTA 400V	£ 192.31
YD22230	22	LOVATO L-STARTER 22KW STAR-DELTA 230V	£ 226.15
YD22400	22	LOVATO L-STARTER 22KW STAR-DELTA 400V	£ 226.15
YD30230	30	LOVATO L-STARTER 30KW STAR-DELTA 230V	£ 300.00
YD30400	30	LOVATO L-STARTER 30KW STAR-DELTA 400V	£ 300.00
Star-Delta Starter Range & Isolator - (Overload needs to be selected at 0.58 x Motor FLC)			
YD11SW230	11	LOVATO L-STARTER 11KW STAR-DELTA 230V + ISOL	£ 229.23
YD11SW400	11	LOVATO L-STARTER 11KW STAR-DELTA 400V + ISOL	£ 229.23
YD15SW230	15	LOVATO L-STARTER 15KW STAR-DELTA 230V + ISOL	£ 238.46
YD15SW400	15	LOVATO L-STARTER 15KW STAR-DELTA 400V + ISOL	£ 238.46
YD22SW230	22	LOVATO L-STARTER 22KW STAR-DELTA 230V + ISOL	£ 315.38
YD22SW400	22	LOVATO L-STARTER 22KW STAR-DELTA 400V + ISOL	£ 315.38
YD30SW230	30	LOVATO L-STARTER 30KW STAR-DELTA 230V + ISOL	£ 430.77
YD30SW400	30	LOVATO L-STARTER 30KW STAR-DELTA 400V + ISOL	£ 430.77
Don't forget to pick your Overload from the table below to go with your Starter.			
Use the below for the DOLC Compact DOL			
RF9.1		0.6-1.0	£ 24.21
RF9.1V5		1.0-1.6	£ 24.21
RF9.2V3		1.6-2.5	£ 24.21
RF9.33		2.5-4.0	£ 24.21
RF9.5		4.0-6.5	£ 24.21
RF9.75		4.5-7.5	£ 24.21
RF9.10		6.3-10	£ 24.21
RF9.15		9.0-14.0	£ 24.21
Use the below for the DOLS Standard DOL			
RF380100		0.6-1.0	£ 26.68
RF380160		1.0-1.6	£ 26.68
RF380250		1.6-2.5	£ 26.68
RF380400		2.5-4.0	£ 26.68
RF380650		4.0-6.5	£ 26.68
RF381000		6.3-10.0	£ 26.68
RF381400		9.0-14.0	£ 26.68
RF381800		13.0-18.0	£ 30.02
RF382300		17.0-23.0	£ 30.02
RF382500		20.0-25.0	£ 30.02
RF383200		24.0-32.0	£ 46.95